

Program update instructions

NOTE: Apple computers are not supported at this time.

A programming cable is included with your Spinal Tap pinball machine and is stored in a plastic wallet in the backbox.



At boot, your pinball machine displays the software version installed on the DMD for about two seconds.

If you look on the Homepin website, you will be able to see if there is a newer version of software available than that installed in your machine. www.homepin.com/tapservice.html

If so, you can download the ZIP file and unpack it to a folder on your PC (ideally a laptop) where you can locate it after download & unzipping.

Plug the programming cable into the black 6 pin socket on the H-0051 board as shown in the picture above. The other end plugs into a USB port of your PC.

Start the updating program by double clicking on the “**Homepin_Update_Tool.exe**” file in the downloaded & unzipped folder (power to the pinball machine should be on).

Once the panel opens, select the correct port for the USB updating cable and then also select the new version of the software you wish to install. Press “Update Game” and another panel will open showing updating is underway.

The START button on the front of your machine will also flash quickly while the machine is being programmed. It will flash more quickly towards the end of the programming.

When it has finished (this could take several minutes) the START button will stop flashing and a window on your PC screen will open to indicate programming has completed.

Unplug the programming cable and reboot your pinball to confirm the new version has been loaded (indicated on the DMD at boot).

IT IS IMPERATIVE THAT ONCE THE UPDATE HAS COMPLETED YOU NAVIGATE TO THE “FACTORY RESET” IN THE SERVICE MENU AND PERFORM A FULL FACTORY RESET FOR THE CHANGES TO TAKE FULL EFFECT

Do NOT unplug or interrupt the programming whilst it is underway or you could brick your machine